





LINERDRAIN DRAIN CLEANING

- Remove the odour trap by turning it counter-clockwise.
- Remove the seal ring from the odour trap and wash the trap and the seal ring using, for example, dish washing liquid.
- Remove loose debris and hair from the drain insert.
- Wash the drain insert by, for example, old dish washing brush, using dish washing liquid.
- Reinstall the seal ring in the odour trap and install the odour trap in its place by turning it clockwise, so that the odour trap engages the mounting stoppers.

MEANS NEEDED FOR FLOOR DRAIN CLEANING

- Rubber gloves
- Dish washing brush
- Cleaning agent
- Washbasin



CLEANING THE PIPE

Resurfaced sewer pipe can be cleaned with normal sewer cleaning equipment (max. pressure 70 bar).

Regular cleaning of the pipeline is recommendable. Cleaning equipment meant for industry pipelines (steam, hot-water, high-pressure or mechanical) must NOT be used.

Do NOT use any chemicals for cleaning the sewer.

CLEARING OF SEWER BLOCKAGES

Sewer blockages can be opened by regular sewer blockage equipment.

Do NOT use any mechanical applications that involves: cutting or milling.

Do NOT use hot water, drain cleaner or other chemicals.

Sewer blockages are usually caused by grease, dirt or object like a toilet freshener. These can be handled by companies specialized in sewer cleaning.

HEAT DURABILITY

Constant heat durability of sewer pipes renovated with inversion method is 60 °C.

CUTTING OF RESURFACED SEWER AND NEW BRANCH INTEGRATION

Instructions for HVAC professionals modifying a resurfaced sewer pipe:

Resurfaced pipes must be cut using spark-free tools, such as a keyhole saw, not by chain cutter.

Other tools may damage the resurfaced sewer pipe.

New sewer pipes are connected to resurfaced sewer in the normal manner, by clamp joints.